

*Integral D00635CI*

WHEN REPLACING PCB ASSEMBLIES, PLEASE WEAR AN ESD WRIST STRAP AND CONNECT IT TO ELECTRICAL GROUND

**RISK OF FIRE AND ELECTRICAL SHOCK**

Contact, improper installation, or improper servicing **MAY RESULT IN DEATH OR SERIOUS INJURY!** Fixture must be installed by a qualified electrician only. Fixture is intended for installation in accordance with the National Electrical Code, local and federal code specifications. Disconnect power at electrical panel before servicing. Retain these instructions for maintenance reference.

**ADVERTENCIA: RIESGO DE INCENDIO O IMPACTO ELÉCTRICO**

Conexión, instalación inapropiada o servicio incorrecto **PUEDE CAUSAR MUERTE O HERIDAS GRAVES.** La luminaria debe ser instalada únicamente por un eléctrico calificado. La luminaria debe instalarse de acuerdo al Norma eléctrica nacional, al igual que especificaciones locales y normas federales. Se debe desconectar la corriente eléctrica antes de realizar la mantención. Conservar estas instrucciones como referencia para futuras mantenciones.






**ATTENTION: RISQUE D'INCENDIE ET D'ELECTROCUTION**

Une installation, un entretien ou un contact physique non conforme pourraient mener à un **DANGER DE MORT OU DE BLESSURE GRAVE!** L'appareil doit être installé uniquement par un électricien professionnel qualifié. L'installation doit respecter le code électrique national de même que les lois locales et fédérales en vigueur. Veuillez fermer l'alimentation électrique au panneau principal avant tout entretien. Conserver ces instructions pour référence et tout entretien futur.




**Maintenance-** Turn off power first

Contact Factory for warranty issues.


1) Be sure to wear ESD protection!

**3 DL****6 DL****9 DL****9 WW****6 Gimbel**

Overview - Internal Driver



Hanger bars provided by ZLI



Standard Housing Dimensions



Size	L	W	H	Wx
3DL	20"	9.5"	4.89"	4.75"
6DL	20"	9.5"	4.89"	4.75"
9DL	20.5"	11.5"	5.64"	5.75"
9WW	20.5"	11.5"	5.64"	5.75"
6G	20"	9.5"	4.89"	4.75"

EM Housing Dimensions

Size	L	W	H	Wx
3DL				
6DL				
9DL	20.5"	13.0"	5.64"	5.75"
9WW	20.5"	13.0"	5.64"	5.75"
6G	20"	11.0"	4.89"	4.75"

\* Light Engine is Centered on Standard Width; EM Version is also Centered on Standard Width

## Wiring - Internal Driver





### 18Ga Pigtail

		Color Codes	
		Black	Switched Hot
		White	Neutral
		Green	Ground
May not be present depending on driver options		Red	Unswitched Hot
		Violet	Control +
		Pink	Control -

## Housing Mounting - Internal Driver

Template to show the hole position



Ceiling Cutout :  
Length=  
Width=


### Ceiling Panel Cutout - EM\*

Size	L	W
3DL	4.45"	1.54"
6DL	8.62"	1.54"
9DL	12.72"	1.54"
9WW	12.72"	1.54"
6G	10.39"	2.36"

Size	L	W	Dia.	W1	L1
3DL					
6DL	8.62"	1.54"	0.394"	0.807"	0.846"
9DL	12.72"	1.54"	0.394"	0.807"	0.846"
9WW	12.72"	1.54"	0.394"	0.807"	0.846"
6G	10.39"	2.36"	0.394"	0.709"	0.846"


\*EM TS drill hole template will be provided for EM Option

## T-Grid Mounting




Size	Wmin
3DL	4.00"
6DL	3.25"
9DL	5.00"
9WW	5.00"
6G	3.75"


## Accessible Sheetrock Mounting - Install before Sheetrock




## EM - Internal Driver




EM TS (Test Switch) Assembly



1




3




Fix the bracket on ceiling by screws


2



5



4




18Ga Pigtail

Color Codes	
Black	Switched Hot
White	Neutral
Green	Ground
Red	Unswitched Hot
Violet	Control +
Pink	Control -

May not be present depending on driver options

## Mounting - Light Engine - Internal Driver



## Install the Light Engine to Housing

