

REMOTECONTROL IR6

Parameter settings









i NOTICE

The REMOTECONTROL IR6 works with the following sensors from Tridonic:

- _ DALI MSensor 02, Article number: 28000897, 28000895, 28000896, 28000894
- _ DSI-SMART PTM, Article number: 28000878, 28000940, 28000877
- _ SMART Sensor 5-10DPI 19fe, Article number: 28000922, 28000929, 28000927, 28000928, 28000923, 28000926, 28000924, 28000925
- _ DALI MSensor 5DPI_14, Article number: 28000935, 28000936
- _ basicDIM Sensor 5DPI_14, Article number: 28000933, 28000934
- _ basicDIM ILD, Article number: 28000905

REMOTECONTROL IR6

Functions

Icon	Designation	Description
	ON	Switch luminaires on → Light regulation is deactivated
	OFF	Switch luminaires off
	Dim up	Increase current dimming level
	Dim down	Decrease current dimming level
	Automatic mode	Switch luminaire on or change to automatic mode → Light regulation is started
	Set current light level	Store the brightness level currently measured by the sensor as target value for constant light control (press button >3 s)